

Ball Screw and Nut Assemblies

Part Number Configuration

HBA - <u>0007</u> - <u>R</u> - <u>A</u> - <u>HBN6311</u> - <u>10.00</u> - <u>3K</u> - <u>A1</u> - <u>T7</u> - <u>S</u> - <u>A</u>

BALL SCREW CODE Ball Screw Size Ball Screw Code .375 x .125 0012 .500 x .200 0016 .500 x .500 0025 .631 x .200 0007 .631 x .500 0017 .750 x .200 0014

Ball Screw Size	Ball Screw Code
.750 × .500	0015
.875 × .200	8000
1.000 × .250	0022
1.000 × .500	0023
1.000×1.000	0024

THREAD DIRECTION

R = Right HandL = Left Hand

MATERIAL -

A = Alloy Steel S = Stainless Steel

BALL NUT PART NUMBER

OVERALL LENGTH (inches)

0000 = No Nut

LEFT END: EZZE MOUNT OR END MACHINING SHAFT EXTENSION

RIGHT END: EZZE MOUNT OR END MACHINING SHAFT EXTENSION

LEAD ACCURACY TOLERANCE GRADE -

 $S = \sim .0003 \text{ in/in}$

$P = \sim .0001 \text{ in/in}$

S = Standard <.004"

S = Standard < .004R = Reduced Lash

ASSEMBLY -

- A = Nut assembled on screw, mounting thread facing left end
- B = Nut assembled on screw, mounting thread facing right end
- U = Nut shipped unassembled from screw on arbor

END MACHINING (see pages 50-51)

1	Type 1	Α	Annealed
2	Type 2	XX	Custom
3	Type 3	00 No End Machining	
4	Type 4		

SHAFT EXTENSION (see pages 50-51)

K	Keyway	
L	No Keyway	
N	No Shaft	

See tables below

or 3N end machining.

in increments of 1.00"

• Single bearing supports are used with Type 1N end

• Double bearing supports are used with Type 3K, 3L,

· For annealed ends, specify length of annealed end

EZZE-MOUNT

	Double Bea	Double Bearing Support ver plate facing thread cover plate away from thread locating boss		ring Support locating boss away from thread	Motor Mount
Universal	B	E	C	n/a	
Flanged	F CO	D C	G	H	Y O

1-855-435-4958